


**Product Information Packet** 

Product Name: Guardrail/Chair Stop Carts



### **Table of Contents**

•	Introduction	1
•	General Safety Rules	2
	Symbols	
	14 Rail Cart Technical Specifications	
•	14 Rail Cart Assembly Instructions	5
	14 Rail Cart Loading Instructions	
	Guardrail/Chair stop Technical Specifications	
	Guardrail/Chair stop Cart Assembly Instructions	_
	Guardrail/Chair stop Loading Instructions	
	Maintenance	
	Customer Service Information	

### Introduction

The Guardrail Cart has been designed and manufactured with safety, performance and dependability as top priorities, making it easy to operate and maintain.

The care you give your Guardrail Cart will greatly determine your satisfaction with its performance and service life. Careful study of this manual is encouraged to obtain a thorough understanding of your new Guardrail Cart and its functions and maintenance.

If your manual becomes lost or destroyed, StageRight will gladly provide you with a new copy. Should you require additional information or assistance, please feel free to contact us at 1-800-438-4499.

BECAUSE STAGERIGHT CORPORATION MAINTAINS AN ONGOING PROGRAM OF PRODUCT DEVELOPMENT AND IMPROVEMENT, WE RESERVE THE RIGHT TO MAKE IMPROVEMENTS IN DESIGN OR CHANGES IN SPECIFICATIONS WITHOUT INCURRING ANY OBLIGATIONS TO INSTALL THEM ON UNITS PREVIOUSLY SOLD.

## **General Safety Rules**




# WARNING! READ AND UNDERSTAND ALL INSTRUCTIONS.

Failure to follow all instructions listed below may result in serious personal injury.

#### **SAVE THESE INSTRUCTIONS**

- Stay clear of all pinch points.
- Make sure that all fasteners are properly engaged before use. Faspins and jam nuts need to be properly engaged before use.
- Save these instructions. Refer to them frequently and use them to instruct others who may use the Guardrail Cart.
- **Read the Product Information Packet.** Failure to read the information packet is considered a misuse of this equipment.
- Become familiar with all caution and warning decals affixed to the staging equipment before use.
- Never cover or deface caution/warning labels.
- Transport carts are designed to carry only STAGERIGHT manufactured guardrails and chair stops.


## **Symbols**




## StageRight Corporation Technical Specifications

### Guardrail Cart

Part #	Description	Weight	Load Capacity
322109	Guardrail Cart	65 lbs	14 Guardrails







#### Construction, Finish, and Hardware

- Constructed of ASTM specified steelBaked-on powder coat finish.Zinc-plated hardware

### Note: Two people recommended for assembly.




Insert the horizontal connection tubes into the vertical end tubes as shown (this step will be necessary for both sides of the cart.) Secure the tubes using (1) 3/8"-16 2  $\frac{1}{2}"$  bolt and (1) 3/8" nut. Be careful not to over tighten the bolts as it could cause deformation of the tubes!



Attach the (4) casters to the frame tubes as shown using (4) 3/8-26 1" bolts (4) 3/8" washers and (4) 3/8"-16 nuts. **Note:** There are (2) swivel casters and (2) fixed casters, be sure to match the caster types on each end for proper functionality. **Be sure to tighten the bolts completely!** Repeat for each caster.

## **Loading Instructions**





Place guardrails on the transport cart as shown. Center the guardrail on the transport cart so that the guardrail's weight is evenly distributed on the tree posts. The Transport Cart is rated to handle 14 guardrails total, 7 on each side. Be sure to load the cart evenly, alternating guardrail placement to avoid tipping the cart over.

## StageRight Product Specifications


Guardrail/Chair-stop cart

Part #	Description	Weight
322202	GRDL/CHSTP	334 lbs





Loading Capacity					
Length	Guardrail	Chair Stop			
4ft	52	90			
6ft	26	45			
8ft	26	45			




#### Construction, Finish, and Hardware


- Constructed of ASTM specified steelBaked-on powder coat finish.Zinc-plated hardware

## **Assembly Instructions**

Note: For your safety, Assembly Will Require Two People



2



# Caution! Chock casters before performing the next step!

With a helper, attach the horizontal tree uprights using (4) 3/8"-16 3" bolts and (4) 3/8-16 nuts and the bottom upright plate to secure the uprights to the cart base. Finger tighten the bolts until all (4) have been located, completely tighten the bolts using a cross pattern to ensure the plate is seated flush with the base surface.

Be mindful of the pinch points created by the plates contacting the base surface. Repeat for all tree uprights.


## **Loading Instructions**

Guardrails Tree Posts

Place guardrails on the support cart as shown. Center the guardrails on the support cart so that the guardrails' weight is evenly distributed on the tree posts. Be sure to load the cart evenly, alternating guardrail placement to avoid tipping the cart over. See chart on Pg. 8 for maximum loading conditions!

2

## Chair Stops



Load chair stops on the bottom of the transport cart as shown. The maximum chair-stop loading capacities are shown in the table in Pg.8

### Maintenance



### WARNING!

#### **Read and Understand All Maintenance Procedures**

Failure to follow all procedures listed below may cause serious injury and a decrease in the equipments functional existence.

- Frequently check to see that all fasteners are properly engaged.
- Touch up paint can be used to cover any scratches or blemishes sustained through use.
- Replace any damaged equipment with genuine StageRight parts. Failure to do so may result in unsafe equipment and/or personal injury.

### **Customer Service**

For parts or service contact StageRight Corporation. When ordering parts be sure to provide all relevant information available including the name and part number of the equipment purchased. This information is located on the technical specification page of this product information package. Customer Service hours are Monday thru Friday from 8:00 a.m. to 5:00 p.m. Eastern Standard Time. Customers can phone toll-free at (800) 438-4499 or mail:

StageRight Corporation 495 Pioneer Parkway Clare, Michigan 48617 www.stageright.com



SET UP IN MINUTES



STURDY, WITH NO TOOLS REQUIRED



UNSURPASSED CUSTOMER SERVICE

StageRight Corporation 495 Pioneer Parkway Clare, MI 48617 Toll-free: 800-438-4499

Phone: 989-386-7393 Email: info@stageright.com

Email: info@stageright.com Web: www.stageright.com